


delvo Brushless Type C Series (Current control type) **Model DLV45C**

Thirty different torque settings can be set on a single screwdriver!

- Current controlled torque system
- Low-voltage brushless motor
- ESD (Electrostatic Discharge) protection structure
- For both hand-held / automated machines (External startup)
- Nine speed settings available
- Automatic three step speed control function
- Two types of measuring methods (Time/Motor rotation signal)
- Seven color indication LED (At the tip of the screwdriver)
- Two external I/O signal connection ports (NPN ↔ PNP switchable, RS-232C)
- Various settings can be configured via a PC (Free setting software available on NITTO KOHKI website)
- Built-in screw counting function


 Lever Start Type
DLV45C12L

 Push to Start Type
DLV45C12P

 Controller
DCC0241X-AZ


Website


delvo

All in one!

Torque and fastening setting of

1st unit

1.2 Nm
1000 min⁻¹

2nd unit

1.8 Nm
500 min⁻¹

3rd unit


3.0 Nm
800 min⁻¹

4th unit


1.8 Nm
500 min⁻¹

delvo Brushless Type C Series (Current control type) Model DLV45C

Brushless Electric Screwdriver for Machine screw (2.5 - 6.0 mm)




1.



Small current

Set value
Torque


2.



Large current

Set value
Torque

3.



Current cutoff

Set value
Torque

1. Start of fastening

At start-up, a small amount of current is allowed.

2. During fastening

As the load increases during fastening, so does the amount of current allowed.

3. End of fastening

When the desired current value (adjusted by corresponding torque value) is reached, current flow is cut off and the screwdriver stops.

Mechanism of
Current Controlled
Torque System

Specifications

| Model | | Bit | DLV45C12L-AY : K | DLV45C12P-AY : K |
|----------------------|------------------------|----------------------|-----------------------------------------------------------------------------------------------|------------------|
| Starting Method | | | Lever Start | Push to Start |
| Power Source | | | From dedicated controller | |
| Torque Adjustment | | | From 1 to 100% in 1% increments | |
| Torque | | (Nm [lbf-in]) | 0.6 to 4.5 [5.3 to 39.8] | |
| Free speed | SOFT fastening setting | (min ⁻¹) | 400 to 1200 | |
| | | Speed Level | Level 1 to 9 | |
| | HARD fastening setting | (min ⁻¹) | 100 to 700 | |
| | | Speed Level | Automatically set by torque setting | |
| Power Consumption | | (W) | 44 | |
| Screw Size | Machine Screw | (mm) | 3.0 to 6.0 | |
| | Tapping Screw | (mm) | 2.5 to 5.0 | |
| Bit Type | | (mm) | | |
| Mass | | (kg [lbs]) | 0.63 [1.39] | |
| Standard Accessories | | | Bit NK35 (No.2x7x75): 1 pc. Connection Cord 2 m (DLW9078): 1 pc. Suspension Bail: 1 pc. | |

| Model | DCC0241X-AZ |
|------------------------------------------|-----------------------------------------------------------------------------------------|
| Input Voltage | 100 - 240 V AC, 50/60 Hz |
| Output Voltage | 40 V DC |
| Input Signal Method | Photocoupler input (24 V DC drive (5 mA/1 input), NPN/PNP switchable) |
| Output Signal Method | Photocoupler output (30 V DC or less, 80 mA/1 output or less, NPN/PNP switchable) |
| Service Power Source | 24 V DC (Maximum capacity 200 mA) |
| Serial Signal Method | RS-232C |
| ESD (Electrostatic Discharge) Protection | Adopted (IEC61340-5-1 compliant) |
| Mass | (kg [lbs]) 1.8 [3.97] |

Caution

*Speed and torque differs depending on the temperature. (Use within the range of +10 to +40°C)

*Do not retighten screws that are already tightened. The torque will become larger than the set torque.

About optional accessories (See page 9 "Optional Accessories")

*The power cord for the controller (DCC0241X-AZ) is sold separately.

Ask us for the required power cord when ordering.

*For torque measurements, please use Nitto Kohki's Torque Checker and Soft Joint / Hard Joint (sold separately).

thirty screwdrivers can be consolidated into one.

5th unit

3.0 Nm
1000 min⁻¹

30th unit

3.0 Nm
400 min⁻¹



Memorizes
thirty
patterns!

Two types of fastening mode available subject to the workpiece and fastening conditions. Coordinate the actual workpieces, screws and operating conditions and determine the fastening mode, torque range and rotation speed.

SOFT / HARD fastening Settings


Instruction manual P68, P69

SOFT fastening setting

Suitable for workpieces with high fastening load such as tapping screws or fastening soft objects such as rubber.

Timing chart

The image of the control action, seating the screw at the set rotation speed.




HARD fastening setting

Suitable for workpieces with small fastening load such as threaded holes or rigid bodies such as metal.

Timing chart

A control that seats the screw at the seating rotation speed according to the torque setting value, when the initial speed time / midterm speed time is elapsed.



*When measuring the torque with Torque Checker, use Soft Joint (DLW4050) for SOFT fastening setting, use Hard Joint (DLW4040) for HARD fastening setting. (See page 9)

Torque range: Output Torque and Rotation Speed


Instruction manual P11, P12

There are nine levels for rotation speed setting. (400 to 1200 min⁻¹)


Corresponds to high torque fastening, even at SOFT fastening setting or slow rotation speed.

(Corresponds to a maximum of 3 Nm at 400 min⁻¹)

Torque Range of SOFT fastening setting



Torque Range of HARD fastening setting




Rotation speed: Built-in automatic speed control function

Instruction manual
P30 to P32

Built-in automatic three step variable speed control function. Enables compatibility of "quality of slow speed" and "efficiency of high speed".




◇ Timing chart (Below rotation speeds and times are examples)



Screw fastening time measuring (Upper / Lower limit)

Instruction manual P32

The upper / lower limit of screw fastening time (correct timer) can be set. It will be judged as "correct fastening" only when the measured time is between the upper limit and lower limit. Either limit can be switched off.



Two types of measuring methods

Instruction manual P41

There are two methods to measure the setting time of start and midterm.



TIME
Measure by time. You can decide the setting value intuitively.




MOTOR SIGNAL
Measure by the motor rotation signal. Even if you change the rotation speed, you do not need to set the measurement time or rotation time.

Rotation direction setting

Instruction manual P37

Specify the rotation direction of forward rotation. "RIGHT" for clockwise, "LEFT" for counterclockwise.



Channel setting

Instruction manual P4, P28, P70

Register up to 30 channels //



The unit of fastening work performed continuously under the same conditions is called a "channel". Up to thirty channels can be registered in the memory.

Example of motion setting


| Channel | CH1 | CH2 | CH3 | CH4 | | CH30 |
|------------------------------------|----------|---------|----------|----------|-------|----------|
| 1: Screw fastening mode | SOFT | SOFT | HARD | SOFT | | HARD |
| 2: Number of screw fastening | 2 pcs. | 13 pcs. | 5 pcs. | 3 pcs. | | 20 pcs. |
| 3: Speed level at finish | Lv5 | Lv9 | AUTO | Lv1 | | AUTO |
| 4: Torque | 10% | 80% | 30% | 45% | | 20% |
| 5: Speed level at start | Lv1 | OFF | Lv9 | Lv3 | | Lv1 |
| 6: Rotation time at start | 0.1 sec. | — | 0.3 sec. | 0.8 sec. | | 1.0 sec. |
| 7: Speed level at midterm | Lv9 | OFF | OFF | Lv8 | | Lv7 |
| 8: Rotation time at midterm | 0.5 sec. | — | — | 1.2 sec. | | 0.5 sec. |
| 9: Speed level at reverse rotation | Lv9 | Lv9 | Lv7 | Lv5 | | Lv5 |
| ⋮ | ⋮ | ⋮ | ⋮ | ⋮ | | ⋮ |
| 26: Rotation direction | RIGHT | RIGHT | RIGHT | LEFT | | RIGHT |

Channel pattern setting



Instruction manual P4, P38, P70

A series of operations combining each channel is called a "channel pattern". Up to eight channels can be registered per channel pattern. Up to thirty channel patterns can be set. When combining nine or more channels, use multiple channel patterns.

Combination up to eight channels //




Example of channel pattern



Setting lock function

Instruction manual P42


Entry of password to enter channel setting mode can be enabled/disabled. Prevents unintended setting change.



Auto reverse function

Instruction manual P35


The screwdriver automatically reverses after torque-up or reaching the preset time. Auto reverse mode can be used for temporarily fastening screws or verifying tapped holes.



Built-in LED function

Instruction manual P19, P37

The LED at the tip of the electric screwdriver is always lit in the specified color. Color coding for each channel is possible. Also, it lights in the specified color when OK(PASS) / NG(FAIL) / count up.



Status in three colors



Controller

- OK(PASS)
- NG(FAIL)
- Count up

Two safety functions

1. Caution mode

Instruction manual P43

A torque value that alerts the operator can be set. After the channel is switched, if the torque exceeds the preset value, a warning is displayed on the counter and the electric screwdriver will not start.

CAUTION
HIGH TORQUE




Flashes in yellow

2. Refastening prohibited time setting

Instruction manual P36

To prevent additional fastening (second tightening, confirmation tightening, etc.), it can be set so that it does not restart after torque-up (for 0.0 to 9.9 seconds).

Adjust the set value according to the skill level of the operator and the interval between screw fastening operations.



Controller Flashes in red

External I/O signal


When connecting to an external device, it can be connected in two ways.

1. External I/O Cable

Instruction manual P47 to P52

Use External I/O Cable DLW9091. Compatible with both NPN/PNP.

It can be wired according to the externally connected equipment.




Connector: IEEE1284 half pitch connector (26-pin)

| Terminal No. | Function | Details | I/O |
|--------------|-------------------------------|--------------------------------------------------------------------------------------------------------------|----------------------|
| 1 | +24 V DC | Built-in service power supply (Capacity: Maximum 200 mA) | Service power supply |
| 2 | 0 V DC | | |
| 3 | Input signal common terminal | Input signal common terminal (See page 49 of instruction manual) | Input |
| 4 | Output signal common terminal | Output signal common terminal (See page 50 of instruction manual) | Output |
| 5 | Switching signal A | Specify channel or channel pattern using a 5-bit input signal. | Input |
| 6 | Switching signal B | | |
| 7 | Switching signal C | | |
| 8 | Switching signal D | | |
| 9 | Switching signal E | | |
| 10 | Forward rotation start | Startup with external input signal. | Input |
| 11 | Reverse rotation start | The electric screwdriver operates while the input signal is ON. | |
| 12 | Workpiece | Input workpiece signal (workpiece detection signal output). Workpiece signal is ON while input signal is ON. | Input |
| 13 | External reset | Input external reset signal | |
| 14 | N/A | No connection | — |
| 15 | Channel A | The channel being operated or being set is ON | Input |
| 16 | Channel B | | |
| 17 | Channel C | | |
| 18 | Channel D | | |
| 19 | Channel E | | |
| 20 | Forward rotation signal | Output signal is ON during forward rotation | Output |
| 21 | Reverse rotation signal | Output signal is ON during reverse rotation | |
| 22 | Operation OK | Output signal is ON when the screw fastening of the set count is complete and judged as operation OK (PASS). | Output |
| 23 | Count up | Output signal ON for 0.3 seconds when screw fastening is normal (at torque-up). | |
| 24 | Operation NG | Output signal ON when workpiece signal is OFF during operation and judged as operation NG (FAIL). | Output |
| 25 | Screw fastening NG | Output signal ON for 0.3 seconds when screw fastening is NG (FAIL). | |
| 26 | N/A | No connection | — |

2. RS-232C

Instruction manual P55 to P58

Use Communication Cable (Straight-through) DLW9092 to connect with PCs or sequencers (PLC).



Connector pin layout
(D-SUB 9-pin (female))

Specifications (RS-232C)

| | |
|----------------------------------------|---------------------------------------------|
| Transmission method | Asynchronous (asynchronous communication) |
| Communication line | Full duplex |
| Transmission speed | 38400 bps |
| Number of data | 8 |
| Parity | None |
| Stop bit | 1 |
| Handshake | None |
| Delimiter (communication separator) | Receive: CR+LF (¥r¥n) Send: CR+LF (¥r¥n) |

| Pin No. | Signal name | I/O |
|---------|-------------|--------------------|
| 2 | TxD | OUT (This tool⇒PC) |
| 3 | RxD | IN (PC⇒This tool) |
| 5 | GND | GND |

*Other pins are not used

Send / receive commands

| Operation | Send command | Response from controller |
|-------------------------------------------|--------------------------|--------------------------------------------------------------------------|
| Forward rotation drive | FWD¥r¥n | FWD¥r¥n |
| Reverse rotation drive | RVS¥r¥n | RVS¥r¥n |
| Drive stop | STP¥r¥n | STP¥r¥n |
| Switching channel / channel pattern *1 | MOV:p¥r¥n (p=1 to 30) | At channel switching CH :p¥r¥n At channel pattern switching CHP:p¥r¥n |
| Screw count reset | CRT¥r¥n | CRT¥r¥n |
| Workpiece reset | WRT¥r¥n | WRT¥r¥n |
| Workpiece signal ON | WIN¥r¥n | WIN¥r¥n |
| Workpiece signal OFF | WOT¥r¥n | WOT¥r¥n |
| Resend request *2 | RSD:p¥r¥n (p=1 to 10) | Command sent nth time before, specified by the parameter value |

*1 The switching target differs depending on the setting of the common setting "Channel change type" (CH CHANGE).
When the channel pattern is switched, the channel is also switched, so the responses are sent continuously.

*2 Up to the latest ten commands sent from the controller to the PC or sequencer are stored.

When signals could not be received correctly due to noise or some other reason, the command of nth time before, specified by the parameter will be sent from the PC or sequencer.

[Example] Send command "RSD:3¥r¥n" → Returns the command sent by the controller three times before.

Since control is performed even when communication between the controller and PC or sequencer fails, use this function when you wish to maintain the reliability of transmission and reception. This command transmission is not included in the ten commands that are stored.

Notification command


| Operation | Notification from controller |
|------------------------------------------------------------------------------------------------------------------------------|------------------------------|
| At forward rotation drive start | FWD¥r¥n |
| At reverse rotation drive start | RVS¥r¥n |
| At drive stop completion | STP¥r¥n |
| Operation OK (PASS) notification | OK ¥r¥n |
| Workpiece signal ON | WIN¥r¥n |
| Workpiece signal OFF | WOT¥r¥n |
| Count up (screw fastening completes normally) notification p = Measured fastening time or signal is output | CUP:p¥r¥n (p=1 to 60000) |
| Operation NG (workpiece out while fastening count remaining) notification | WNG¥r¥n |
| Screw fastening NG (FAIL) notification p1=Screw fastening NG (FAIL) No. p2=Measured fastening time or signal is output | FNG:p1:p2¥r¥n |
| At channel switching | CH :p¥r¥n (p=1 to 30) |
| At channel pattern switching | CHP:p¥r¥n (p=1 to 30) |
| When a non-supported command or parameter is input | CER¥r¥n |

In addition to RS-232C signals, commands are sent from the controller to the PC or sequencer(PLC) when processing is performed manually or by contact signals.

1. External I/O Cable



DLW9091




Insert the separately sold External I/O Cable DLW9091 to the external signal connector to connect between the terminal and wiring.

2. RS-232C



DLW9092



Insert the separately sold Communication Cable (Straight-through) DLW9092 to the RS-232C connector to connect to a PC or sequencer (PLC).

Easy setting with dedicated software


Channels and Channel patterns can be easily set with dedicated software. Download free from our website.



Website

<http://www.nitto-kohki.co.jp/prd/delvo/>

◇ Setting software top page







Channel setting

Channel pattern setting

Common setting


Communication Cable (Straight-through) DLW9092



Setting data transmission function between controllers

📖 Instruction manual P45

The channel and channel pattern settings can be transmitted to another controller. This is very convenient when the same work is divided into multiple processes.




Communication Cable (Crossover) DLW9093

Vacuum Sleeves and applicable Bits

Unit: mm


◇ Vacuum Sleeve DLS4000 series



| Model | Ød | ØD | L1 | L2 | Length | Applicable Bit *2 | Shape (Type) | Part No. |
|------------|------|------|-----|----|--------|-------------------|--------------|----------|
| DLS4220 | 9.1 | 11 | 5 | 6 | 45 | No.2x7x75 | A | TD08001 |
| DLS4221 | 10.6 | 12.5 | 5.5 | 7 | | No.2x7x75 | A | TD08002 |
| DLS4222 *1 | 8 | 11 | 5.3 | 22 | | — | A | TD07850 |
| DLS4223 *1 | 8.2 | 10 | 5 | 6 | | No.2x7x75 | A | TD07851 |
| DLS4224 *1 | 6.8 | 9 | 25 | — | | — | C | TD07852 |
| DLS4225 | 4.6 | 7 | 25 | 20 | | No.1x4x75 | B | TD09344 |
| DLS4226 | 5.1 | 7 | 25 | 20 | | No.1x4x75 | B | TD09617 |
| DLS4227 | 5.6 | 7 | 25 | 20 | | No.2x4x75 | B | TD09345 |
| DLS4228 | 6.1 | 9 | 25 | — | | No.2x4x75 | C | TD09618 |
| DLS4229 | 6.4 | 9 | 25 | — | | No.1x4x75 | C | TD09619 |
| DLS4230 | 7.1 | 9 | 25 | — | | No.2x4x75 | C | TD09620 |

*1) Made-to-order product *2) Select the correct size number that fits your screw head

◇ Applicable Bit NK35



| No. | ØD | L | Part No. |
|-----|----|----|----------|
| 1 | 4 | 75 | TD20306 |
| | 7 | 50 | TD20308 |
| | 7 | 75 | TD20309 |
| 2 | 4 | 50 | TD20316 |
| | 4 | 75 | TD20317 |
| | 7 | 50 | TD20319 |
| 3 | 7 | 75 | TD20320 |
| | 7 | 50 | TD20327 |
| | 7 | 75 | TD20328 |

* See delvo general catalog for other bit types.

Optional Accessories

Grounded 3-Prong Power Cord 2 m

DLW9220
North America



DLW9240
Europe



DLW9250
UK



Diamond Shape Flange Coupling
DLW9017



For mounting on automated
screw fastening machines

Flange Coupling
DLW9019



For mounting on automated
screw fastening machines

Screw Vacuum Pump
DLP2540 (115 V AC), DLP2570 (230 V AC)



Connect the tube to the vacuum pickup port.
The vacuum will pick up the screw.

Vacuum Pickup
DLP7401-K



For screw vacuum pickup

Vacuum Sleeve
DLS4000 series



Select according to the screw shape

Torque Checker
DLT1673A



For torque control of screwdrivers

Soft Joint
DLW4050

Bit is included



The bit for measuring is included.
(NK35BN 13×19×10×75)

For SOFT fastening
torque measurement

Hard Joint
DLW4040

Bit is optional



The bit for measuring is not included.
(NK35BN 13×19×10×75)

For HARD fastening
torque measurement

External I/O Cable 3 m
DLW9091



Connect when using external signals

Communication Cable 3 m
(Straight-through)
DLW9092



Connect to PCs and PLCs (sequencers)
when using external signals

Communication Cable 3 m
(Crossover)
DLW9093



Connect controllers to transmit settings

Extension Cord 3 m
DLW9310



Extends cord length between
controller and screwdriver

Connection Cord 2 m
DLW9078

Standard
accessory of
screwdrivers



Connects controller and screwdriver

Pistol Grip
DLW2300ESD


ESD Protection




For operator fatigue reduction,
suitable for horizontal fastening

External Dimensions

DLV45C12L-AY



DLV45C12P-AY



unit: mm [inch]


Example of installation on automated machines

Can be mounted on
desktop robots,
Cartesian robots,
6-axis robots, etc.




External Dimensions


When Flange Coupling DLW9019/DLW9017 is mounted





When Flange Coupling and Vacuum Pickup DLP7401-K is mounted



When Vacuum Pickup DLP7401-K is mounted



Controller DCC0241X-AZ



unit: mm [inch]

delvo

NITTO KOHKI CO., LTD.

Web www.nitto-kohki.co.jp/e

Head Office

9-4, Nakaikegami 2-chome, Ohta-ku, Tokyo 146-8555, Japan

Tel : +81-3-3755-1111 Fax : +81-3-3753-8791

E-mail : overseas@nitto-kohki.co.jp



ISO 9001
JQA-2025
ISO 14001
JQA-EM4057
H.Q./R&D Lab

DISTRIBUTED BY